


Mill Fixtures

Snap fixture starter kit
for Model Master mills

Included Parts



Snap Receiver

Includes T-nuts and Allen head bolts for mounting on rotary Axis.



Alignment Bar

Used for installation.
(See installation guide)



Snap Adapters

Are used to attach the different material holders to the snap Adapters


For information call 252-558-0351
E-mail: info@millfixtures.com

Mill Fixtures



4 Jaw Chuck Adapter

Used to adapt your existing Model Master 4 jaw chuck to the Snap Adapter



Ring Fixture

Used for rotary machining of rings



Quick release tube holder

Can hold a tube up to 6" long. Equipped with a quick release button.

For information call 252-558-0351
E-mail: info@millfixtures.com